

VALOR



**Classic Type
Unvented Gas Fired Room Heaters
MODELS**

- 271VP - Propane Gas
- 271VN - Natural Gas
- 272VP - Propane Gas
- 272VN - Natural Gas


REPAIR PARTS LIST

Distributed by


F.B.D. Inc.

**601 Hope Street,
Bowling Green, Ky 42101
(502) 796-8406.**



Because our Policy is one of constant development and improvement, details may vary slightly from those given in this publication.




271VN



271VP



272VN



272VP

KEY	DESCRIPTION	SPARE No.	Quantity per Appliance			
			MODEL			
			271VN	271VP	272VN	272VP
1	CASE ASSEMBLY	508439	1	1	-	-
		508579	-	-	1	1
2	REFLECTOR UNIT	502529	1	1	-	-
		502919	-	-	1	1
3	REFLECTOR APRON	502549	1	1	-	-
		502929	-	-	1	1
4	LOWER FRONT PANEL	504409	1	1	-	-
		504449	-	-	1	1
5	SAFETY GUARD UNIT	503809	1	1	-	-
		503159	-	-	1	1
6	SAFETY GUARD CLIP	502579	2	2	2	2
7	BURNER UNIT (Includes key 8)	503449	1	-	-	-
		508559	-	1	-	-
		508599	-	-	1	-
		508659	-	-	-	1
8	JET & HOLDER	508459	3	-	5	-
		508599	-	3	-	5
9	PILOT & IGNITION UNIT	503329	1	-	1	-
		502099	-	1	-	1
10	PIPE ASSEMBLY - PILOT TO PILOT REGULATOR	519959	1	-	-	-
		519999	-	-	1	-
10A	COUPLING	503279	2	-	2	-
11	PILOT REGULATOR	523889	1	-	1	-
12	PIPE ASSEMBLY - PILOT REGULATOR TO VALVE	519999	1	-	-	-
		520009	-	-	1	-
13	PIPE ASSEMBLY - LEFT SIDE RADIANT TO VALVE	508479	1	1	-	-
14	PIPE ASSEMBLY - CENTRE RADIANT TO VALVE	508489	1	-	-	-
		508839	-	-	1	1
15	PIPE ASSEMBLY - RIGHT SIDE RADIANT TO VALVE	508499	1	1	-	-
16	CONTROL VALVE	508519	1	1	1	1
17	VALVE LOCKNUT	502739	1	1	1	1
18	VALVE WASHER	502749	1	1	1	1
19	PIPE ASSEMBLY - VALVE TO PRESSURE TEST TAPPING UNIT	508529	1	1	-	-
		504159	-	-	1	1
20	PRESSURE TEST TAPPING UNIT	502179	1	1	-	-
		503399	-	-	1	1
21	REGULATOR	519979	1	-	1	-
		508209	-	1	-	1
22	INLET ELBOW	503519	1	1	1	1
23	CONTROL KNOB	502759	1	1	1	1
24	CONTROL SHAFT UNIT	502769	1	1	1	1
25	WALL BLANKING PLATE	502589	1	1	-	-
		502959	-	-	1	1
26	PIPE ASSEMBLY - PILOT TO VALVE	508469	-	1	-	-
		508609	-	-	-	1
27	PIPE ASSEMBLY - OUTER RADIANTS TO VALVE	508619	-	-	1	1
28	PIPE ASSEMBLY - RADIANTS 2 & 4 TO VALVE	508629	-	-	1	1
29	ADAPTOR	503859	-	-	1	1
-	INSTRUCTION MANUAL	508539	1	1	1	1

